




GreenFingers

Introduction

GreenFingers is a unique 4-in-1 sensing device that allows you to monitor your plants' specific growing requirements in real-time through your smartphone. Connect to the GardenGeek GreenFingers App for access to your plants' needs as well as professional growing tips

What does your GreenFingers device monitor?



GreenFingers App installation

Please log on to our website to install the iOS or Android GreenFingers App:
www.gardengeek.com/greenfingersapp/



QR code for iOS App installation



QR code for Android App installation

How to use your GreenFingers device

1. Open the back cover of the GreenFingers device, take out the insulation sheet inside the battery compartment, and replace the cover.



2. Insert the GreenFingers device into the plants' pot or garden soil. If the soil is too dry, try watering it before inserting the device.




3. Turn on Bluetooth on your smartphone, select the + sign in the top right corner on GreenFingers App Home screen and follow the prompts on the App to add your GreenFingers device. The light sensor will flash twice once your phone is successfully connected to the device.



Usage notes



Ensure the sensor surface is clean before inserting.



Ensure at least 2/3 of the soil moisture sensor section is inserted into the soil



Ensure there are no obstructions to the light sensor



Never immerse the white section in water

Safety precautions

This product contains a battery.

1. Keep battery out of reach of children. Do not allow children or animals to chew or suck the device.
2. Rain or water immersion will cause the product to malfunction.
3. Do not heat, put heavy load on, or destroy the battery pack.
4. When the battery runs out or if the product is stored for long time, remove the batteries.
5. Replacement batteries need to meet the specification indicated in the manual.

Product Details

Product Model: HHCCJCY01HHCC
 Applicable Standards: Q/CYHHCC0001 – 2015
 Dimensions: 120.5 X 24.5 X 12.5 mm
 Bluetooth Version: 4.1
 Power Source: 3V
 Battery Model: CR2032
 CMIIT ID: 2016DP0940
 FCC ID: 2AJEPHHCCJCY01HHCC

Limited Service Warranty

Gardengeek Pty Ltd. ("GARDENGEEK") warrants the included hardware product against any of the defects listed in the Product Defect List for six months from the date of original purchase. This warranty is restricted to products sold by GARDENGEEK or a GARDENGEEK Authorised Reseller, within the Republic of South Africa. To obtain service, call GARDENGEEK. Call charges and shipping costs may apply.

Warranty benefits are in addition to rights provided under the Consumer Protection Act in South Africa. Full terms and detailed information about obtaining returns or warranty service are available at www.gardengeek.com/returns-policy/.

GARDENGEEK offers the following return, exchange and repair services free of charge for the device, provided the applicable conditions are met:

Service Type	Service Policy
Return	Return of unused product in original packaging within 30 days from the date of receipt of product
Exchange	Exchange or replacement of defective or faulty product within 30 days from the date of receipt of product
Repair	Repair of defective product within 6 months warranty period from the date of receipt of product

The warranty period will not be extended or renewed due to subsequent resale, GARDENGEEK authorised repair or replacement of the product.

This limited warranty does not cover:

- Defects other than those listed in the Product Defect List.
- Normal wear and tear; defects caused by negligence, abuse or rough handling (including, but without limitation, defects caused by sharp objects, bending, compression, or dropping, etc.); defects or damage caused by misuse or improper use of the product (including use that contrary to the instructions set out in this user guide); torn or altered labels; or other acts beyond the reasonable control of GARDENGEEK.
- Defects caused by short-circuiting of the battery, or by broken seals of the battery enclosure or evidence of tampering.
- Products which have been opened, modified or repaired by anyone other than a GARDENGEEK Authorised Repair Agent.
- Products which have been exposed to extreme thermal or environmental conditions or rapid changes in such conditions, or products which have been subject to damage caused by corrosion, oxidation, force majeure, liquid ingress or chemical products.
- Transport costs and risks of transport.

Product Defect List	
GreenFingers	Malfunction of Bluetooth of the product
	Product sensor does not work

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- this device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The distance between user and products should be no less than 20cm

ICASA Compliance




Environment-Friendly Use Period (EFUP)

Item Name	Hazardous Substances					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)
White plastic case	○	○	○	○	○	○
Hard plastic	○	○	○	○	○	○
Metal	○	○	○	○	○	○
PCB board	×	○	○	○	○	○

This form is prepared in accordance with the provisions of S.J / T 11364.

○ : Indicates that the amount of this toxic or hazardous substance in all homogeneous materials under this item are below the limit required by GBT 26572 – 2011 Requirement on Usage Limit of Restricted Substances in Electrical and Electronic Products.

× : Indicates that the amount of this toxic or hazardous substance in at least one homogeneous materials under this item are above the limit required by GBT 26572 – 2011 Requirement on Usage Limit of Restricted Substances in Electrical and Electronic Products.



Correct Disposal



This product and the batteries in this product should not be disposed of with other household waste.
 This product is RoHS compliant.